




IBL FTM 110K
500W FOOT MASSAGER

INSTRUCTION MANUAL

NOTE: DO NOT USE WITHOUT THE WATER






IBL FTM 110K 500W FOOT MASSAGER

Thank you for choosing our product, our products are designed and manufactured to the highest standards to deliver high quality performance,as well as easy installation and use We believe in providing not only service,but adding value to your purchase.The warranty has therefore been designed especially for you with your interest at heart.

Model	Rated Voltage	Rated Frequency	Rated Power	Working Time	Using Temperature	Rated Capacity	Safety Design
KW530-C2	220-240V	50Hz	500W	30mins	48°C+/-3°C	10L	
Executive Standard: GB/T26206-2010							



Note:DO NOT use the Foot Spa Massager machine without the water

To avoid the risk of fatalities from electric shock:

- Make certain that the power cord does not become wet or moist during operation. Place it such that it cannot be crushed or damaged.
- DO NOT use the Foot Spa Massager machine without the water
- Keep the power cable away from hot surfaces.
- DO NOT carry out any repairs on the appliance. All repairs must be carried out by the manufacturer or its service agent or a similarly qualified person.
- Unplug the appliance before filling it with water or cleaning it.
- Arrange for defective power plugs and or cables to be replaced as soon as possible by a qualified technician or by our Customer Service Department to avoid the risk of injury.

To avoid the risk of fatalities from electric shock:

- The appliance is not intended for use by children or other persons without assistance or supervision if their physical, sensory or mental capabilities prevent them from using it safely. Children should be supervised to ensure that they do not play with the appliance.
- Consult with your doctor before using the foot spa should you be suffering from vein inflammation, inflamed varicose veins, water retention or rashes on your legs.
- Take care if you are not sensitive to heat. You may not realize how hot the foot support plate can get.
- Never operate the appliance with blocked air-inlet openings. Take care that the air-inlet openings do not become blocked through dust, hair etc.

To avoid damaging the device:

- DO NOT stand in or on the foot spa. Use it only while seated.
- DO NOT use the Foot Spa Massager machine without the water.
- Never operate the foot spa for longer than 60 minutes. The appliance is not meant to be used continuously for long periods. Allow the appliance to cool sufficiently before using it again.
- DO NOT use any foam-producing bath additives. The appropriate bath additives for bubble baths are available from specialized dealers.
- DO NOT fall asleep while using the foot spa.
- Never operate the appliance while you sleep.

INTENDED USE

This foot spa is intended for personal, home use. Its function is only to bathe and massage the feet. It is not suitable for any other purpose. It is not intended for use in the medical/therapeutic or commercial fields.

DELIVERY ITEMS/APPLIANCE DESCRIPTION

- Digital Panel.
- Cover.
- Water drainage.
- Roller massager.
- Operating instruction

OPERATION

Set up

1. Add the warm water or water to the tub before plug in
2. Plug in the Foot Massager Spa
3. Heating
The foot tub starts heating. The default temperature is 45 degrees. At this time, you can press the heating button to set the temperature at 35-48 degrees. Turn on the massage function after the temperature reaches the appropriate temperature.
4. Manual massage roller
5. Timer
Press to set timer which ranges between 10 minutes to 60 minutes (10-20-30-40-50-60 minus).
6. Machine working time
The working time is 30 min.
7. After the foot bath
Turn the appliance off by pressing POWER and remove the plug from the electrical socket.

TECHNICAL

Ratedvoltage: 220 - 240 V ~50Hz

Ratedoutput: 500W

COTime: 30min

The CO Time (Continuous Operation Time) details how long an appliance can be operated without the motor overheating and becoming damaged. After the appliance has run for this period it must be switched off until the motor has cooled it self down.

FUNCTIONS OF THE FOOT SPA

Heat: The heating technology heats the water inside and provides for a water temperature. Control heat using. May take upto 10 min to heatup.

2. Massage: The foot rollers with massage nubs create through vibration a pleasant massage effect.

3. pleasant massage effect.

4. Timer: Press to set timer which ranges between 10 minutes to 60 minutes(10-20-30-40-50-60minus).

Danger of an electric shock!

- Try not to over fill. Otherwise, water could over-flow during the foot spa.
- First connect the appliance to the power source when you have filled it with water.
- Fill the water bath with warm or cold water.
- Note: The purpose of the heating function is not to heat cold water.
- It should simply maintain the temperature of the water.

WARNINGS

- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.

- Children shall not play with the appliance. Cleaning and maintenance shall not be made by children without supervision.

Using the foot spa

1. Now place your feet in the water container.
2. During the water bath you can massage the soles of your feet by moving your feet forward and backward on the 8 strong rollers.

Caution:

Do not exceed the maximum operating period of 20 minutes! The appliance could be irreparably damaged. Danger of overheating.

After the foot bath

1. Turn the appliance off by pressing POWER and remove the plug from the electrical socket.
2. Carefully empty the water out through the water drainage pipe which is installed on the back.
3. Then rest for awhile.

CLEANING

Warning! Risk of injury!

- Unplug the appliance, before cleaning it.
- Let the appliance cool sufficiently before cleaning it.
- Never immerse the appliance in water or other liquids to clean it.

Warning!

- Do not use any aggressive cleaning liquids or solvents. They could damage the surface.
- Do not use it without water